

Form 3210W
(462)
Printed in U. S. A.

LIST OF PARTS COMPLETE


FOR

MACHINE NOS. 300W103 and 300W203

HISTORICAL COPY
300W103 and 300W203
MACHINE NOS.

THE SINGER MANUFACTURING COMPANY

LIST OF PARTS COMPLETE
FOR



MACHINE No. 300W103
TWO THREAD CHAIN STITCH
ONE NEEDLE. ONE LOOPER.
COMPOUND FEED.
ALTERNATING PRESSERS.
MAXIMUM STITCH 3 1/2 TO THE INCH
NEEDLE BAR STROKE 1 1/4 INCHES.
PRESSER BAR LIFT 3/8 INCH.

FOR WELTING, BINDING, MATTRESSES and SEAMING
MEDIUM and HEAVY FABRICS

No.	Plate	Name
*267601	-----	Arm with 201485C, 204235, 267602, 267635, 268004, two each 3554, 200039H, three each 200029E and 200047D
*267602	-----	Arm Head with 200351C and 200417C
204235	18640	" " Position Pin
200029E	18640	" " Screw
3582	18640	" " Position Pin (2)
200004E	18640	" " Screw (4)
267603	18632	" " Shaft with 268009, 268044, 268264, two each 268214 and 350534C
268024	18632	Arm Shaft Ball Bearing (back)
268004	18632	" " " " " Housing
200047D	18632	" " " " " Screw
268005	18632	" " " " " (front)
267604	18640	" " Side Cover
268006	18632	Arm Shaft Connection Belt Pulley with two each 201254C and 201253
201254C	18632	Arm Shaft Connection Belt Pulley Set Screw

PARTS FOR MACHINE No. 300W103

No.	Plate	Name
202253	18632	Arm Shaft Connection Belt Pulley Spring Flange
268732	18632	Arm Shaft Counter Balance with 200354C and 200362C
200354C	18632	Arm Shaft Counter Balance Position Screw
200362C	18632	" " " " " Set Screw
268264	18632	" " " " " Oil Control Rod (wood)
268008	18632	" " " " " Slinger with 350171C
350171C	18632	" " " " " Set Screw
268214	18632	" " " " " Stop Ball, 5/32 in. diameter
350534C	18632	" " " " " Screw
268009	18632	" " " " " Spring (front)
268044	18632	" " " " " " (rear)
267604	18640	" " Side Cover
267661	18640	" " " " " Oil Shield with 244411 and 267662
267662	18640	Arm Side Cover Oil Shield Pin
248411	18640	" " " " " " " Staples
200078H	18640	" " " " " Screw (4)
268048	18632	Balance Wheel "V" belt groove (outside diam. of belt groove 2.9 in.) with 200342C and 200347C
268049	18632	Balance Wheel 268048 with 204224
200342C	18632	" " " " " Position Screw
200347C	18632	" " " " " Set Screw
*268401	-----	Bed with 268184, two each 200035E and 226881
265307	18640	" " Hinge Connection (4)
200553H	18640	" " " " " Screw (4)
267605	18640	" " Plate (left)
268018	18640	" " " (right)
200053H	18640	" " " " " Screw (8)
267606	18640	" " " " " Slide with two 268022 and four 200154H
268022	18640	Bed Plate Slide Spring
200154H	18640	" " " " " " " Screw
263160	18632	" " Shaft with 268044, 268214, 261253 and 350534C
268024	18632	Bed Shaft Ball Bearing
268028	18632	" " " " " Connection Belt Pulley with two 201254C
268261	18632	Bed Shaft Connection Belt Pulley 268024 with 268024
201254C	18632	Bed Shaft Connection Belt Pulley Set Screw
268732	18632	" " " " " Counter Balance with 200354C and 200362C
200354C	18632	Bed Shaft Counter Balance Position Screw
200362C	18632	" " " " " " " Set Screw
268029	18632	" " " " " Needle Bearing (2)
268265	18632	" " " " " Oil Control Rod (wood)
350534C	18632	" " " " " " " Screw
268044	18632	" " " " " " " Spring
201253	18632	Bed Shaft Connection Belt Pulley with two 201411C
268021	18640	Face Plate Hinge Pin (2)
201411C	18640	" " " " " " " Set Screw
200353C	18640	" " " " " " " Flange
268032	18640	" " " " " " " Lock Spring

PARTS FOR MACHINE No. 300w103

No.	Plate	Name
268197	18640	Face Plate Lock Spring Plate
200571XC	18640	" " " " Screw (2)
268033	18640	" " " " Stud
268034	18634	Feed Bar with 200373C and two 200403C
268035	18634	" " " " Hinge Pin
202574	18634	" " " " Collar with 200380C
200380C	18634	" " " " " Set Screw
200403C	18634	" " " " Set Screw
268618	18643	" " Dog with 268318 and two 200172D, for 268614
200100C	18643	Feed Dog Screw (2)
268318	18634	" " Shank with 201537H and 350552C
350552C	18634	" " " " Adjusting Screw
201537H	18634	" " " " " Lock Nut
200040AL	18634	" " " " " Screw
201125E	18634	" " " " " Lock Nut
208636	18634	" " " " " Washer
267608	18634	" " Driving Connection
267609	18634	" " " " 267608 with 271055
268062	18634	" " " " Hinge Stud with 268258
201122E	18634	Feed Driving Connection Hinge Stud Nut
268258	18634	" " " " " " Oil Packing (wick)
271055	18634	Feed Driving Connection Needle Bearing
267610	18633	" " " " Eccentric
268065	18633	" " " " " Adjusting Disc
268066	18633	" " " " " " Spring
268067	18633	Feed Driving Eccentric Adjusting Disc Spring Collar with two 200382C
200382C	18633	Feed Driving Eccentric Adjusting Disc Spring Collar Set Screw
267623	18633	Feed Driving Eccentric Friction Plate
350548C	18633	" " " " " " " Screw
350477C	18633	" " " " " " " " Set Screw
		Feed Driving Eccentric Friction Plate Screw
		Set Screw Packing (brass)
268115	18633	Feed Driving Flange with 267623, two each 241763, 350467AL, 350477C and 350548C
350467AL	18633	Feed Driving Flange Set Screw
268064	18634	" " " " Rock Frame with 200058C and 200382C
		Feed Driving Rock Frame Position Screw
200382C	18634	" " " " " Set Screw
268070	18634	" " " " " Shaft
268072	18634	" " " " " Collar with two 200386C (2)
200061C	18634	Feed Driving Rock Shaft Collar Set Screw
268073	18634	" " " " " Crank with 201418C and two 200061C
200061C	18634	Feed Driving Rock Shaft Crank Pinch Screw
201418C	18634	" " " " " " Position Screw
268071	18634	" " " " " Needle Bearing (2)
268074	18634	" " Lifting Connection
268062	18634	" " " " Hinge Stud with 268258
201122E	18634	Feed Lifting Connection Hinge Stud Nut

PARTS FOR MACHINE No. 300w103

No.	Plate	Name
268258	18634	Feed Lifting Connection Hinge Stud Oil Packing (wick)
268075	18634	Feed Lifting Crank with 200373C and 201256C
201256C	18634	" " " " Pinch Screw
268047	18635	" " " " Eccentric with 268077 and two 200394C
268077	18635	Feed Lifting Eccentric Lubricating Pad (wood)
200394C	18635	Feed Lifting Eccentric Set Screw
268078	18634	" " " " Link
268079	18634	" " " " Hinge Pin with 268258 (2)
268258	18634	" " " " " " Oil Packing (wick)
200373C	18634	Feed Lifting Link Hinge Pin Set Screw
268080	18634	" " " " Rock Shaft
268072	18634	" " " " " Collar with two 200386C (2)
200386C	18634	Feed Lifting Rock Shaft Collar Set Screw
268198	18634	" " " " " Crank with 201418C and two 200061C
200061C	18634	Feed Lifting Rock Shaft Crank Pinch Screw
201418C	18634	" " " " " " Position Screw
268071	18634	Feed Lifting Rock Shaft Needle Bearing (2)
268081	18633	" " " " Regulating Stud
240245	18633	" " " " Retaining Spring
268082	18633	" " " " " Socket
200073F	18633	" " " " " " Screw (2)
270026	18633	" " " " " Spring
267611	18638	Foot Lifter Arm with 200058C and 200373C
200058C	18638	" " " " " Pinch Screw
200373C	18638	" " " " " Set Screw
267612	18638	" " " " " Crank
200650H	18638	" " " " " Stop Screw Stud
268085	18638	" " " " " Lever (back) with 238084
201383C	18638	" " " " " Hinge Screw
204348	18638	" " " " " Spring
201456C	18638	" " " " " " Screw
201160E	18638	" " " " " " Eye
267612	18638	" " " " " (front) with 267614
267614	18638	" " " " " Hinge Pin
203941	18633	" " " " " Spring
201160E	18638	" " " " " " Eye
350524X	18638	" " " " " Rod Hinge Screw
201515E	18638	" " " " " " " Washer
206133	18638	" " " " " " Washer
267615	18638	" " " " " Rod
267616	18638	Lifting Crank with 200167E, 200418C and two 200061D
200061D	18638	Lifting Crank Pinch Screw
200418C	18638	" " " " " Set Screw
268064	18632	" " " " " Eccentric
268065	18632	" " " " " Adjusting Disc
267618	18632	" " " " " Spring
267619	18632	" " " " " Connection
267620	18631	" " " " " 267618 with 268063

PARTS FOR MACHINE No. 300w103

No	Plate	Name
267621	18638	Lifting Eccentric Connection Crank with 201063D and two 200058C
200058C	18638	Lifting Eccentric Connection Crank Pinch Screw
267617	18638	Lifting Eccentric Connection Hinge Pin with 244071
244071	18638	Lifting Eccentric Connection Hinge Pin Oil Packing (wick)
201063D	18638	Lifting Eccentric Connection Hinge Pin Pinch Screw
268062	18632	Lifting Eccentric Connection Needle Bearing
267622	18632	" " Flange with 267623, two each 241753, 350467AL, 350477C and 350548C
350467AL	18632	Lifting Eccentric Flange Set Screw
267623	18632	" " Friction Plate
350548C	18632	" " " " " " Screw
350477C	18632	" " " " " " Set Screw
241753	18632	Lifting Eccentric Friction Plate Screw Set Screw Packing (brass)
267624	18632	Lifting Eccentric Spacing Collar with two 200362C
200362C	18632	Lifting Eccentric Spacing Collar Set Screw
267625	18636	" Lever with two 267693
267626	18636	" " " " Hinge Stud
200362C	18636	" " " " " " Set Screw (2)
267693	18636	" " " " Needle Bearing
267627	18636	" Link
267617	18638	" " " " Hinge Pin with 244071 (2)
244071	18638	" " " " " " Oil Packing (wick)
200167E	18638	" " " " " " Set Screw
267628	18636	" Presser Bar
267629	18636	" " " Guide Block with 200066D and 200081C
200066D	18636	Lifting Presser Bar Guide Block Pinch Screw
200081C	18636	" " " " " " " "
200417C	18636	" " " " " " " " Set Screw Flowing
200461C	18636	Lifting Presser Bar Guide Rod Set Screw Support
267631	18636	Lifting Presser Bar Lifting Crank with 267632
268258	18636	Lifting Presser Bar Lifting Crank Oil Packing (wick)
267632	18643	Lifting Presser Foot with 200016F, for 267659
200016F	18643	Lifting Presser Foot Guide Block with 200016F
267633	18638	" Rock Shaft
267634	18638	" " " " " " " " with 20012 and 267635
267635	18638	Lifting Rock Shaft Bracket
8554	18638	" " " " " " Position Pin
200016B	1-1864	" " " " " " " " Screw

[illegible]

PARTS FOR MACHINE No. 300w103

No.	Plate	Name
200444C	18635	Looper Throw-out Gear Locking Plunger Stop Screw
200364C	18635	Looper Throw-out Gear Locking Plunger Stop Screw Set Screw
201620D	18635	Looper Throw-out Gear Locking Plunger Thumb Nut
200362C	18635	Looper Throw-out Gear Set Screw
268129	18635	" " Rack Rod
268314	18635	" " " " 268129 with 201553D
201553D	18635	Looper Throw-out Rack Rod Thumb Nut
268131	18634	" " Safety Latch
268109	18634	" " " " Collar with two 200386C
200386C	18634	Looper Throw-out Safety Latch Collar Set Screw
268132	18634	Looper Throw-out Safety Latch Bar and 268133 " " " "
		Bracket
200098F	18634	Looper Throw-out Safety Latch Spring Bracket Screw (2)
223443	18635	Machine Mounting Stud (4)
268603	18635	Needle Bar with 200125F
268137	18635	" " Connecting Link
268138	18635	" " " " 268137 and 200379C and two 270266
268139	18635	Needle Bar Connecting Link Cap Washer
200095H	18635	" " " " " " " "
		Screw
270266	18635	Needle Bar Connecting Link Needle Bearing
200125F	18635	" " " " " " " "
		200423 and two 200069C
200423	18635	Needle Bar Connecting Stud Oil Packing (twice)
200069C	18635	Needle Bar Connecting Stud Pinch Screw
268142	18632	" Crank with 200346C, 200354C, 200378C and 200379C
268143	18632	Needle Bar Crank Pinch with 200379C
200379C	18632	" " " " Oil Hole Plug Screw
200378C	18632	" " " " " " " "
		" " " " " " " " Cap Screw
200346C	18632	Needle Bar Crank Set Screw
268144	18635	" " " " " " " "
268145	18635	" " " " " " " "
200173D	18635	" " " " " " " " Screw (4)
267537	18635	" " " " " " " " " "
267638	18635	" " " " " " " " Driving Arm with two 200043C
200043C	18635	Needle Bar Rock Frame Driving Arm Pinch Screw
267639	18632	" " " " " " " " " "
267609	18632	" " " " " " " " " "
		267608 with 271053
200123D	18635	Needle Bar Rock Frame Driving Connection Cap Screw

PARTS FOR MACHINE No. 300W103

No.	Plate	Name
268062	18636	Needle Bar Rock Frame Driving Connection Hinge Stud
201522E	18636	Needle Bar Rock Frame Driving Connection Hinge Stud Nut
271055	18632	Needle Bar Rock Frame Driving Connection Needle Bearing
267610	18632	Needle Bar Rock Frame Driving Eccentric
268065	18632	" " " " " "
		Adjusting Disc
267639	18632	Needle Bar Rock Frame Driving Eccentric Flange with 267633 two each 241763, 350467AL, 350477C and 350548C
350467AL	18632	Needle Bar Rock Frame Driving Eccentric Flange Set Screw
267623	18632	Needle Bar Rock Frame Driving Eccentric Friction Plate
350548C	18632	Needle Bar Rock Frame Driving Eccentric Friction Plate Screw
350477C	18632	Needle Bar Rock Frame Driving Eccentric Friction Plate Screw Set Screw
241763	18632	Needle Bar Rock Frame Driving Eccentric Friction Plate Screw Set Screw Packing (brass)
268029	18636	Needle Bar Rock Frame Needle Bearing (2)
268148	18632	" " " " Regulating Stud
264709	18632	" " " " " " Cap with 200364C
200364C	18632	Needle Bar Rock Frame Regulating Stud Cap Set Screw
268149	18632	Needle Bar Rock Frame Regulating Stud Sleeve
214529	18632	Needle Bar Rock Frame Regulating Stud Sleeve Set Screw
214529	18632	Needle Bar Rock Frame Regulating Stud Spring
268150	18632	Needle Bar Rock Frame Regulating Stud complete, Nos. 214529, 264709, 268148 and 268149
268219	18616	Needle Bar Rock Frame Thread Guide
200583C	18616	" " " " " " " Screw (2)
200125F	18636	Needle Set Screw
268312	18641	" Thread Guide (on Arm Head)
268512	18636	" " " " (on Needle Bar Connecting Stud)
201733C	18636	Needle Thread Guide (on Needle Bar Connecting Stud) Set Screw
200032D	18641	Needle Thread Guide Screw
201733XC	18641	" " " " Nipper Adjusting Collar with 350101AL
350101AL	18641	Needle Thread Nipper Adjusting Collar Screw
268222	18641	Needle Thread Nipper Bearing
268222	18641	" " " " " Plate
200064D	18641	" " " " " " Screw (2)
268223	18641	Needle Thread Nipper Disc (2)

PARTS FOR MACHINE No. 300W103

No.	Plate	Name
268224	18641	Needle Thread Nipper Disc Washer (vellumoid)
268225	18632	Needle Thread Nipper Eccentric with two 200394C
268226	18632	Needle Thread Nipper Eccentric Connection
268228	18632	" " " " " "
		268226 with 268227
268227	18632	Needle Thread Nipper Eccentric Connection Needle Bearing
268259	18632	Needle Thread Nipper Eccentric Flange
201403H	18632	" " " " " " Set Screw
200394C	18632	" " " " " " Set Screw
268229	18641	" " " " " Plunger with 350496C
268230	18641	" " " " " Cap
268231	18641	" " " " " Hinge Pin
350496C	18641	" " " " " " Set Screw
222513	18641	Needle Thread Nipper Spring
216232	18641	" " " " " " Flange
201537H	18641	" " " " " " Nut (2)
350483C	18641	" " " " " " Spring Bearing
268167	18641	Needle Thread Tension Bracket
200047E	18641	" " " " " " Screw (2)
268121	18641	" " " " " " Spacing Collar (2)
2102	18641	Needle Thread Tension Disc
268168	18641	" " " " " Releaser
268169	18641	" " " " " " Cap with 201052C
201052C	18641	Needle Thread Tension Releaser Cap Set Screw
204365	18641	Needle Thread Tension Releaser Spring
32572	18641	" " " " " Releasing Disc
225206	18641	" " " " " " Pin
268171	18638	" " " " " " Plate (adjustable)
238069	18638	Needle Thread Tension Releasing Plate Pin
131741	18641	" " " " " Spring
59538	18641	" " " " " " Bushing (back)
59537	18641	" " " " " " " (front)
50325C	18641	" " " " " Stud
59539	18641	" " " " " " 50525C arm
51570C		51570C
54279	18641	Needle Thread Tension Thread Guide (double)
268263	18641	Needle Thread Tension Thread Guide (double) 59537 to 59539, 131741 and two 2102
267641	18638	Presser Bar Spring
267642	18638	" " " " " Arm
267643	18636	" " " " " " Bar Sewing Retainer
201403H	18636	" " " " " " " " Screw (2)
267644	18638	Presser Bar Spring Arm Fork

PARTS FOR MACHINE No. 300w103

No.	Plate	Name
267645	18638	Presser Bar Spring Arm Fork Lock Washer (nylon)
267646	18638	Presser Bar Spring Arm Fulcrum
201254C	18638	" " " " " Set Screw (2)
267647	18638	Presser Bar Spring Arm Hinge Buffer (leather)
267648	18638	Presser Bar Spring Housing
267660	18638	Presser Bar Spring Housing complete, Nos. 200186H, 267641, 267644, 267645, 267648, 267651, 267652, 267654 and 267655
201824E	18638	Presser Bar Spring Housing Adjusting Nut (1)
201824H	18638	Presser Bar Spring Housing Oil Screw
2018278C	18638	" " " " " Set Screw
244084	18638	" " " " " " " Packing (fibre)
200378C	18638	Presser Bar Spring Housing Support with 200378C and 244084
267670	18638	Presser Bar Spring Housing Support Retainer
200026F	18638	" " " " " " " Screw (2)
267671	18638	Presser Bar Spring Plunger
267652	18638	" " " " " " " Bearing with 267653
267653	18638	Presser Bar Spring Plunger Bearing Bushing (oil retaining)
267654	18638	Presser Bar Spring Plunger Cap
267655	18638	" " " " " " " Washer (leather)
267656	18638	Spreader with 268162
267657	18638	" " " " " " " Bar
267658	18638	" " " " " " " Bearing
267659	18638	" " " " " " " Position Pin
200100E	18605	" " " " " " " Screw
267660	18605	" " " " " " " Driving Connection with two 201020E
267661	18605	Spreader Driving Connection 268186 with 200078F and 200100E
200360E	18605	Spreader Driving Connection Cap Screw
267662	18605	" " " " " " " Needle Bearing
267663	18605	" " " " " " " Crank with 200360C and 200403C
200360C	18605	Spreader Driving Crank Position Screw
200403C	18605	" " " " " " " Set Screw
267664	18605	" " " " " " " Crank with two 200360C
200360C	18638	Spreader Driving Eccentric Counter Balance Set Screw
267665	18638	Spreader Driving Eccentric Set Screw
267666	18638	" " " " " " " Thrust Washer (2)
267667	18638	Spreader Driving Pin
267668	18605	" " " " " " " Rock Shaft
267669	18605	" " " " " " " Collar with two 200360C (2)

PARTS FOR MACHINE No. 300w103

No.	Plate	Name
200386C	18605	Spreader Driving Rock Shaft Collar Set Screw
268071	18605	Spreader Driving Rock Shaft Needle Bearing (2)
350466C	18605	Spreader Driving Rock Shaft Screw Stud
351876	18605	" " " " " " " Ball Roller
201736E	18605	Spreader Driving Rock Shaft Screw Stud Nut
268185	18605	" " " " " " " Holder with two 200380C
200380C	18605	" " " " " " " Set Screw
200380C	18605	" " " " " " " Point
350149C	18605	" " " " " " " Screw
204925	18605	" " " " " " " Washer
267656	18640	Thread Lubricator with 50608R, 134017, 350549C and three 236957
236957	18640	Thread Lubricator Oil Pad (felt)
350549C	18640	" " " " " " " Regulating Screw
50608R	18640	" " " " " " " Plug Screw
134017	18640	" " " " " " " Washer
200064D	18640	" " " " " " " Screw
268614	18640	Throat Plate for 268618
200100E	18640	" " " " " " " Screw (3)
267657	18638	Vibrating Presser Bar
267658	18638	" " " " " " " Hinge Stud
267659	18640	" " " " " " " Foot with 200078F and 267632
200078F	18640	Vibrating Presser Foot Pinch Screw

PARTS FOR MACHINE No. 300w203

MACHINE No. 300w203

TWO THREAD CHAIN STITCH

TWO NEEDLES. TWO LOOPERS.
COMPOUND FEED.

ALTERNATING PRESSERS.
MAXIMUM STITCH 3 1/2 TO THE INCH

NEEDLE BAR STROKE 1 1/4 INCHES.
PRESSER BAR LIFT 3/4 INCH.

FOR LAP SEAM FELLING and INSERTING SLEEVES
in SPORT SHIRTS and SIMILAR WORK in
MEDIUM and HEAVY FABRICS

MADE IN GAUGES FROM 7/16 TO 1 INCH

Same as Machine No. 300w201, but the following
exceptions:

No.	Plate	Name
267300	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in gauges 7, 9 and 11, 32 in. (teeth cut 15 to the inch) with two 268317 and four 200172D, for 267350
267302	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in gauges 1, 4, 9, 32 and 5/16 in. (teeth cut 15 to the inch) with two 268318 and four 200172D, for 267351
267304	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in gauges 11, 12, 13, 8 and 13, 32 in. (teeth cut 15 to the inch) with two 268318 and four 200172D, for 267353
267312	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in gauges 7, 15, 15, 32 and 1/2 in. (teeth cut 15 to the inch) with two 268318 and four 200172D, for 267355
267317	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in gauges from 11, 32 to 21, 32 in. in steps of 1/32 in. (teeth cut 15 to the inch) with two 268318 and four 200172D, for 267357
267321	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in gauges from 11, 16 to 31, 32 in. in steps of 1/32 in. (teeth cut 15 to the inch) with two 268318 and four 200172D, for 267358
267325	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in 1 in. gauge, teeth cut 15 to the inch, with two 268318 and four 200172D, for 267359
267326	18644	Lifting Presser Foot, for 267359, in gauges from 7, 16 to 11, 32 in. in steps of 1/32 in. with 200073F
267377	18644	Lifting Presser Foot, for 267380, in gauges from 7, 16 to 11, 32 in. in steps of 1/32 in. with 200073F

No.	Plate	Name
268317	18644	Loop Deflector
268088	18639	Looper (2)
268103	18639	" Holder, in gauges from 3/16 to 11, 32 in., in steps of 1/32 in., with four 350478C
268104	18639	Looper Holder, in gauges from 3/8 to 5/8 in., in steps of 1/32 in., with four 350478C
268105	18639	Looper Holder, in gauges from 21, 32 to 7/8 in., in steps of 1/32 in., with four 350478C
268106	18639	Looper Holder, in 20, 11, 15, 16, 31, 32 and 1 in. gauge, with four 350478C
268296	18639	Looper Thread Guide (on Bed at Looper) for gauges from 1, 16 to 15, 32 in.
268297	18639	Looper Thread Guide (on Bed at Looper) for gauges from 1, 16 to 15, 32 in.
268298	18639	Looper Thread Guide (on Bed at Looper) for gauges from 1, 16 to 15, 32 in.
268121	18642	Looper Thread Tension Release Pin (1)
5089	18642	Looper Thread Tension Release Pin (2)
268130	18637	Needle Bar
268219	18639	" Rock Frame Thread Guide, in gauges from 1, 16 to 11, 32 in. in steps of 1/32 in.
268254	18639	Needle Bar Rock Frame Thread Guide, in gauges from 1, 16 to 11, 32 in.
268255	18639	Needle Bar Rock Frame Thread Guide, in gauges from 21, 32 to 7/8 in. in steps of 1/32 in.
268256	18639	Needle Bar Rock Frame Thread Guide, in 20, 32, 15, 16, 31, 32 and 1 in. gauge
268151	18639	Needle Holder, in gauges from 1, 16 to 11, 32 in., in steps of 1/32 in., with two 30014C
268152	18639	Needle Holder, in gauges from 1, 8 to 1, 8 in., in steps of 1, 14 in., with two 30014C
268154	18639	Needle Holder, in gauges from 21, 32 to 7/8 in., in steps of 1, 32 in., with two 30014C
268156	18639	Needle Holder, in 20, 32, 15, 16, 31, 32 and 1 in. gauge, with two 30014C
30014C	18639	Needle Set Screw
226206	18642	" Thread Tension Releasing Pin (1)
54279	18642	" Thread Tension Releasing Pin (2)
268263	18642	Needle Thread Tension Complete, Nos. 103721, 50517 to 54530, 131741 and two 2101, 2)
268173	18639	Springer, in gauges from 1, 16 to 11, 32 in. in steps of 1/32 in., with two 268152
268175	18639	Springer, in gauges from 1, 8 to 1, 8 in. in steps of 1, 32 in., with two 268152
268176	18639	Springer, in gauges from 21, 32 to 7/8 in. in steps of 1, 32 in., with two 268152
268180	18639	Springer, in 20, 32, 15, 16, 31, 32 and 1 in. gauge
267850	18644	Throat Plate, for 267300, in gauges 1, 16 and 11, 32 in.
267851	18644	Throat Plate, for 267302, in gauges 1, 4, 9, 32 and 5/16 in.
267853	18644	Throat Plate, for 267304, in gauges 11, 12, 13, 8 and 13, 32 in.

PARTS FOR MACHINE No. 300w203

No.	Plate	Name
267855	18644	Throat Plate, for 267812, in gauges 7/16, 15/32 and 1/2 inch
267857	18644	Throat Plate, for 267817, in gauges from 17/32 to 21/32 in., in steps of 1/32 inch
267858	18644	Throat Plate, for 267821, in gauges from 11/16 to 31/32 in., in steps of 1/32 inch
267859	18644	Throat Plate, for 267825, in 1 in. gauge
267679	18644	Vibrating Presser Foot, 40 needle hole, in gauges from 3/16 to 11/32 in., in steps of 1/32 in., with 200078F, for 267676
267680	18644	Vibrating Presser Foot, 40 needle hole, in gauges from 3/8 to 1 in., in steps of 1/32 in., with 200078F, for 267677

ACCESSORIES

ACCESSORIES

FOR MACHINE No. 300w103

No.	Plate	Name
62x59	-----	Needles, six, size 22
228443	18612	Drip Pan
200019E	18612	" " Screw (2)
210805	18612	" " " Washer (2)
502843	18612	" " " " (leather) (4)
288280	18611	Looper and Needle Bar Setting Gauge
26x276	18611	" Threading Wire
111461	18612	Machine Base Oil Drain Jar (glass)
111462	18612	" " " " " Cap
131138	18612	" " " " " " Clamp
131117	18612	" " " " " " " 131188
		with 131189
131189	18612	Machine Base Oil Drain Jar Clamp Lever
1247C	18612	" " " " " " " Screw
131166	18612	" " " " " " " Nipple (short)
228452	18612	Machine Base Oil Drain Jar complete, Nos. 131217, 131266, 131951, 131962 and two 1247C
228320	18645	Machine Cushion (felt) (4)
228444	18645	" " (neoprene) (4)
41400	18611	" Rest Pin (wood)
228449	18645	" Support (left) with two wood screws 1-1/4 in., No. 12, F. H. B.
228450	18645	Machine Support (right) with two wood screws 1-1/4 in., No. 12, F. H. B.
228491	18611	Pressure Oiler
228498	18611	Screw Driver (7-1/4 in. long)
255542	18611	" " (8 in. blade)
228476	18611	" " (Bobbin Case)
27739	18611	Thread Cone (wood) (2)
228477	18611	Thread Cone
228511	18611	Wrench
228900	18611	Wrench
249820	18611	Wrench
255540	18611	" (steel)

FURNISHED ONLY WITH MACHINES ORDERED

FOR 30 W. 1000. ORDERED INSTALLATION

41401	18611	Machine Rest Pin (wood) (in place of 41400)
228460	18645	" Support (left) with two wood screws 1-1/4 in., No. 12, F. H. B. (in place of 228449)
228461	18645	Machine Support (right) with two wood screws 1-1/4 in., No. 12, F. H. B. (in place of 228450)

FOOT LIFTER TREADLE

No.	Plate	Name
228716	18646	Treadle
228474	18646	" Chain, 34 in. long, with two 202784
202784	18646	" " Hook
14373	18646	" Extension
50581R	18646	" " Screw
2718R	18646	" " " Washer
17881	18646	" Shaft
14374	18646	" Spring
14375	18646	" Stand
228717	18646	Foot Lifter Treadle complete, Nos. 17881, 14373 to 14375, 17881, 50581R and 2718R

THREAD UNWINDER FOR TWO SPOOLS

228647	18627	Base with two 200141C
228642	18627	Spool Pin
201528H	18627	" " Nut
228693	18627	" " Washer
225257	18627	" Rest (for two spools) (flat with 201018C, two each 201528H, 228693 and 228694)
150203	18627	Spool Rest Cushion (felt)
228648	18627	" " Rod
200341C	18627	" " " Set Screw
201018C	18627	" " " Set Screw
228649	18627	Thread Tube with two 268125
268125	18627	" " " Blasting
350101AL	18627	" " " Set Screw
228647	18627	350101AL
201139H	18627	Thread Tube Support Set Screw
228650	18627	Thread Unwinder complete, for two spools, Nos. 228647, 228648, 228693, 228694, each 150203, 228649 and three 41401 screws 1-1/4 in., No. 14, F. H. B.

FOR MACHINE No. 300w103

Same as Machine No. 300w103 with the following exceptions:

501528	18627	Needle Rest (in place of 12)
27739	18611	Thread Cone (wood) (4)

ACCESSORIES

THREAD UNWINDER FOR FOUR SPOOLS

No.	Plate	Name
228647	18628	Base with two 200341C
228692	18628	Spool Pin
201528H	18628	" " Nut
228692	18628	" " Washer
225257	18628	" " Rest (for two spools) (flat) with 201015C, two each 201528H, 228692 and 228651
150207	18628	Spool Rest Cushion (felt)
228648	18628	" " Rod
200341C	18628	" " Set screw
201015H	18628	" " Set screw
228651	18628	" " Stud
228651	18628	" " Support with 201528H two 228652 and eight 350101A1
201015H	18628	Spool Rest Support Set screw
228649	18628	Thread Guide with two 228115
228115	18628	" " Bushing
350101A1	18628	" " Set screw
228652	18628	Thread Guide Support complete, for four spools, Nos. 228647, 228648, 228651, two 225257, four each 150203, 228649 and three wood screws 1-4, 4 in. 1-6, 1-4, 2, 11, 3.

FEED DOGS

FOR MACHINE No. 300W103

267804	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in gauges 11, 12, 13, 14 and 15, 16 in. (teeth cut 15 to the inch) with two 268318 and four 200172D, for 267853
--------	-------	--

FOR MACHINE No. 300W203

267809	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in gauges 11, 12, 13, 14 and 15, 16 in. (teeth cut 15 to the inch) with two 268318 and four 200172D, for 267853
267811	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in gauges 11, 12, 13, 14 and 15, 16 in. (teeth cut 15 to the inch) with two 268318 and four 200172D, for 267853

FEED DOGS

No.	Plate	Name
267804	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in gauges 11, 12, 13, 14 and 15, 16 in. (teeth cut 15 to the inch) with two 268318 and four 200172D, for 267853
267812	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in gauges 11, 12, 13, 14 and 15, 16 in. (teeth cut 15 to the inch) with two 268318 and four 200172D, for 267853
267817	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in gauges 11, 12, 13, 14 and 15, 16 in. (teeth cut 15 to the inch) with two 268318 and four 200172D, for 267853
267821	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in gauges 11, 12, 13, 14 and 15, 16 in. (teeth cut 15 to the inch) with two 268318 and four 200172D, for 267853
267825	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in gauges 11, 12, 13, 14 and 15, 16 in. (teeth cut 15 to the inch) with two 268318 and four 200172D, for 267853
267815	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in gauges 11, 12, 13, 14 and 15, 16 in. (teeth cut 15 to the inch) with two 268318 and four 200172D, for 267853
267819	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in gauges 11, 12, 13, 14 and 15, 16 in. (teeth cut 15 to the inch) with two 268318 and four 200172D, for 267853
267826	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in gauges 11, 12, 13, 14 and 15, 16 in. (teeth cut 15 to the inch) with two 268318 and four 200172D, for 267853
267831	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in gauges 11, 12, 13, 14 and 15, 16 in. (teeth cut 15 to the inch) with two 268318 and four 200172D, for 267853
267834	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in gauges 11, 12, 13, 14 and 15, 16 in. (teeth cut 15 to the inch) with two 268318 and four 200172D, for 267853
267835	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in gauges 11, 12, 13, 14 and 15, 16 in. (teeth cut 15 to the inch) with two 268318 and four 200172D, for 267853
267837	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in gauges 11, 12, 13, 14 and 15, 16 in. (teeth cut 15 to the inch) with two 268318 and four 200172D, for 267853

FEED DOGS

No.	Plate	Name
267838	18644	Feed Dog, 40 needle hole, for needle sizes 23 and 24, in 1 in. gauge (teeth cut 8 to the inch) with two 268318 and four 200172D, for 267859

LOOPER HOLDERS

FOR MACHINE No. 300w103

268002	18616	Looper holder with two 350478C
--------	-------	--------------------------------

FOR MACHINE No. 300w203

268103	18628	Looper holder, in gauges from 3 to 11 32 in. in steps of 1 32 in., with four 350478C
268104	18629	Looper holder, in gauges from 1 8 to 5 8 in., in steps of 1 32 in., with four 350478C
268105	18630	Looper holder, in gauges from 21 32 to 7 8 in., in steps of 1 32 in., with four 350478C
268106	18631	Looper holder, in 29 32, 15 16, 31 32 and 1 in. gauge, with four 350478C

LOOPER THREAD GUIDES

(on Bed at Looper)

FOR MACHINE No. 300w103

268296	18616	Looper Thread Guide (on Bed at Looper)
--------	-------	--

FOR MACHINE No. 300w203

268296	18639	Looper Thread Guide (on Bed at Looper) for gauges from 3 16 to 15 32 inch
268297	18640	Looper Thread Guide (on Bed at Looper) for gauges from 1 2 to 25 32 inch
268298	18641	Looper Thread Guide (on Bed at Looper) for gauges from 15 16 to 1 inch

NEEDLE BAR ROCK FRAME THREAD GUIDES

FOR MACHINE No. 300w103

No.	Plate	Name
268219	18616	Needle Bar Rock Frame Thread Guide

FOR MACHINE No. 300w203

268219	18622	Needle Bar Rock Frame Thread Guide, in gauges from 3 16 to 11 32 in. in steps of 1 32 in.
268254	18639	Needle Bar Rock Frame Thread Guide, in gauges from 1 2 to 1 3 in. in steps of 1 32 in.
268255	18639	Needle Bar Rock Frame Thread Guide, in gauges from 21 32 to 7 8 in. in steps of 1 32 in.
268256	18639	Needle Bar Rock Frame Thread Guide, in 29 32, 15 16, 31 32 and 1 in. gauge

NEEDLE HOLDERS

FOR MACHINE No. 300w203

268151	18639	Needle Holder, in gauges from 3 16 to 11 32 in., in steps of 1 32 in., with two 300140
268152	18639	Needle Holder, in gauges from 3 8 to 5 8 in., in steps of 1 32 in., with two 300140
268153	18639	Needle holder, in gauges from 21 32 to 7 8 in., in steps of 1 32 in., with two 300140
268154	18639	Needle holder, in 29 32, 15 16, 31 32 and 1 in. gauge, with two 300140

DRESSED FEET

FOR MACHINE No. 300w203

267632	18643	Lifting Presser Foot with 200075F for 267654
267633	18643	Vibrating Presser Foot with 200075F for 267632

PRESSER FEET

FOR MACHINE No. 300w203

No.	Plate	Name
267676	18644	Lifting Presser Foot, for 267679, in gauges from 3/16 to 11/32 in., in steps of 1/32 in., with 200078F
267677	18644	Lifting Presser Foot, for 267680, in gauges from 3/8 to 1 in., in steps of 1/32 in., with 200078F
267679	18644	Vibrating Presser Foot, 40 needle hole, in gauges from 3/16 to 11/32 in., in steps of steps of 1/32 in., with 200078F, for 267676
267680	18644	Vibrating Presser Foot, 40 needle hole, in gauges from 3/8 to 1 in., in steps of 1/32 in., with 200078F, for 267677

SPREADERS

FOR MACHINE No. 300w103

268606	18616	Spreader with 268162
--------	-------	----------------------

FOR MACHINE No. 300w203

268177	18639	Spreader, in gauges from 3/16 to 11/32 in., in steps of 1/32 in., with two 268162
268178	18639	Spreader, in gauges from 3/8 to 5/8 in., in steps of 1/32 in., with two 268162
268179	18639	Spreader, in gauges from 21/32 to 7/8 in., in steps of 1/32 in., with two 268162
268180	18639	Spreader, in 29/32, 15/16, 31/32 and 1 in. gauge, with two 268162

THROAT PLATES

FOR MACHINE No. 300w103

268614	18643	Throat Plate, for 268618
--------	-------	--------------------------

THROAT PLATES

FOR MACHINE No. 300w203

No.	Plate	Name
267850	18644	Throat Plate, for 267800, in gauges 3/16 and 7/32 inch
267851	18644	Throat Plate, for 267802, in gauges 1/4, 9/32 and 5/16 inch
267853	18644	Throat Plate, for 267804, 267815 and 267819, in gauges 11/32, 3/8 and 13/32 inch
267855	18644	Throat Plate, for 267811, 267828 and 267831, in gauges 7/16, 15/32 and 1/2 inch
267857	18644	Throat Plate, for 267817 and 267834, in gauges from 17/32 to 21/32 in., in steps of 1/32 inch
267858	18644	Throat Plate, for 267821, 267835 and 267837, in gauges from 11/16 to 31/32 in., in steps of 1/32 inch
267859	18644	Throat Plate, for 267845 and 267858, in 1 in. gauge